
EXHIBIT P

HTC 10

Unlocked Devices

User guides

Top articles

FAQ

Getting Started

Your first week with your new phone

HTC Sense Home

Sleep mode

Lock screen

Motion gestures

Touch gestures

Getting to know your settings

Using Quick Settings

Capturing your phone's screen

Travel mode

Restarting HTC 10 (Soft reset)

Notifications

Turning icon badges on or off

Motion Launch

Selecting, copying, and pasting text

Entering text

How can I type faster?

Getting help and

Motion gestures

Use motion gestures to mute HTC 10, lower the ring volume, and more.

Lift phone to auto answer a call

To automatically answer an incoming call, lift the phone and look at the screen first to see who's calling before you hold it to your ear.

You can turn this feature on or off. In **Settings > Call**, select or clear **Auto answer calls**.

Flip to mute



If your phone is facing up when a call comes in, turn the phone over to mute it.

Go to Settings and then tap **Sound** or **Sound & notification**. Tap **Advanced > Flip to mute**, and you can set your phone to:

Mute once Mute only once after flipping the phone. While the phone is still facing down, it will ring again when there are other incoming calls.

Mute always After flipping the phone to mute a call, keep it always muted while it's still facing down when there are other incoming calls.

Pick up to lower volume



In a business meeting or restaurant, pick HTC 10 up when a call comes in to lower the ring volume automatically.

You can turn this feature on or off. Go to Settings, tap **Sound** or **Sound & notification**. Tap **Advanced**, and then tap the Quiet ring on pickup **On/Off** switch.

Increase ring volume automatically while phone is in your pocket or bag

What's new

Unboxing and setup

Updates

Calls, Messages, and Contacts

Connectivity

Personalizing

Camera

Battery and Storage

Backup, Transfer, and Reset

Applications

Settings



Pocket mode makes HTC 10 recognize when your phone is in your bag or pocket and raise the ring volume so that you can hear it in noisy environments. You can turn this feature on or off. Go to Settings, tap **Sound** or **Sound & notification**. Tap **Advanced**, and then tap Pocket mode **On/Off** switch.

Rotate HTC 10 for a better view



For many screens, you can automatically change the screen orientation from portrait to landscape by turning HTC 10 sideways. When entering text, you can turn HTC 10 sideways to bring up a bigger keyboard.

Was this information helpful?

Yes No

RELATED ARTICLE

Muting the ringing sound without rejecting the call

Motion Launch

Find topics about HTC 10

Type what you're looking for

Get Help

USA |

© 2011-2018 HTC Corporation

Privacy Policy | Product Security

CONNECT

SMARTPHONES

- HTC U11
- HTC U11 life

TEAM HTC NEWSLETTER

LEGAL

- Privacy Policy
- Learn More
- Terms of Use
- Code of Conduct
- Copyright
- Product Security
- Cookies
- Virtual Patent Marking
- HTC Trademark Usage Guidelines
- Proposition 65

MORE PRODUCTS

- Fitness
- VIVE
- VIVEPORT

SOFTWARE + APPS

ABOUT HTC

- Company Overview
- Press & Media Room
- Investor
- Device Security
- Working at HTC

ACCESSORIES

- HTC U11 Accessories
- HTC U11 life Accessories
- HTC U Ultra Accessories
- HTC 10 Accessories
- HTC Bolt Accessories

INNOVATIONS

- Edge Sense
- HTC Transfer Tools
- Power to Give

SITES

- HTC Partners
- HTC Dev
- HTC Research

HTC FINANCING

SUPPORT

- Devices & Accessories
- Order Help
- Order Status
- Returns & Cancellations
- Shipping Information
- FAQs
- Warranty Policy

HTC CAMPUS STORE

Copyright 2011-2018 HTC Corporation. All rights reserved.

Accessibility
Recycling