MODERN DICTIONARY of

ELECTRONICS

Rudolf F. Graf

SIXTH EDITION

name is familiar to engiind hobbyists. His many actricity, electronics and utation for making comand enjoyable. Mr. Grafecceived his MBA at New er of the IEEE, a licensed of a first-class radiotelea the electronics industry

SAMS


A Division of Prentice Hall Computer Publishing 11711 North College, Carmel, Indiana 46032 USA

IPB-BCM_00024979





Case 2:16-cv-00134-JRG-RSP Document 67-2 Filed 08/26/16 Page 65 of 200 PageID #: 4479



IPB-BCM_00024980



600

he edge of the dielectric is wound.

rating at the borderland mits of voltage, current, when operation is margill impairment can cause tem to fail.

ing — Also called margieventive maintenance in perating conditions (e.g., or frequency) are varied order to locate defects bee serious.

A relay with a small its nonoperative current a current applicable withand its operative value rent that operates the

1g - See Marginal Check-

ed card—A card in which ing data are punched only with the center left free for red information.

ed information.

cast station — A coastal

regularly broadcasts the

rological and hydrograph-

beacon station — A 1 land station, the emisich are used to determine direction of a ship in relaine radiobeacon station.

ile service—The radio serships communicate with with coastal and other land cified frequencies.

ionavigation service—A ntended to be used for the

legraphy, the closed-circuit, the signal that closes the sceiver to produce a click of r to print a character on a 2. The presence of signal, se is equivalent to a binary which originated with televate a closed key condition, implies the presence of curon a circuit or the idle contypewriter. It also indicates igit one in computer lang, 1.4. In rtty applications, to of two states. The mark is characterized by a closed space, the other state, is by an open-circuit con-

ace impulses — In neutral a teletypewriter system, the is the closed-circuit signal, impulse is the open-circuit her than neutral operation, sulse is the circuit condition the same result in the terment that a mark impulse

601

marker-mask

produces in neutral operation. Similarly, the space impulse is the circuit condition that produces the same result in the terminal equipment that a space impulse produces in neutral operation.

produces in neutral operation.

marker — Also called marker beacon. A radio navigational aid consisting of a transmitter that sends a signal to designate the small area around and above it.

marker antenna — The transmitting

antenna for a marker beacon. marker beacon—See Marker.

marker generator—An rf generator that injects one or more pips of specific frequency onto the response curve of a tuned circuit being displayed on the screen of a cathode-ray oscilloscope.

cathode-ray oscilloscope.

marker pip — The inverted V (Λ) or spot of light used as a frequency index mark in cathode-ray oscilloscopes for alignment of tv sets. It is produced by coupling a fixed-frequency oscillator to the output of a sweep-driven signal generator.

marker thread — A colored thread laid parallel and adjacent to the strands of an insulated conductor which identifies the wire manufacturer and often the specification under which the wire is constructed. marking-and-spacing intervals—In telegraphy, the intervals corresponding to the closed and open positions, respectively, of the originating transmitting con-

marking bias — Bias that affects the results in the same direction they are affected by marking current

results in the same direction they are affected by marking current.

marking current — The magnitude and polarity of line current when the receiving mechanism is in the operated condition.

marking pulse—The signal interval during which the selector unit of a teletypewriter is operated.

marking wave—Also called keying wave. In telegraphy, the emission while the active portions of the code characters are being transmitted.

mark sense—1. To mark a position on a punch card, using a special pencil that leaves an electrically conductive deposit for later conversion to machine punching.

2. A mechanized technique of punching data into computer cards. A graphite line positioned on the card is read electronically and converted into holes by special equipment.

mark-sense card - A card designed to permit data to be entered on it with an

electrographic pencil.

mark sensing—A technique for detecting
special pencil marks entered in special
places on a card and automatically translating the marks into punched holes.

mark-to-space transition—The change from a marking impulse to a spacing impulse. marshalling sequence — See Collating Sequence, 1.

maser—1. Acronym for microwave amplification by stimulated emission of radiation. A low-noise microwave amplifier in which a signal is boosted by changing the energy level of a gas or crystal (commonly, ammonia or ruby, respectively). 2. A means of focusing a stream of particles, which concentrates only on the high-energy particles. These are passed into a resonator which is resonating at the radiation frequency of the particles. The particles are in this state raised to a strong oscillation, and can be used for control purposes. By reducing the flow of particles to the resonator, to maintain oscillations, it can be used as an amplifier (There are many other applications). 3. Device for amplifying a microwave frequency signal by "stimulated emission of radiation"—i.e., the weak microwave signal causes electrons in an atom to change orbit in such a manner as to emit an amplified signal of the same frequency as the weak signal.

television picture tube to limit the view-ing area of the screen. 2. A device (usually a thin sheet of metal which contains an open pattern) used to shield selected por-tions of a base during a deposition proc-ess. 3. A device used to shield selected portions of a photosensitive material during photographic processing. 4. A logical technique in which certain bits of a word are blanked out or inhibited. 5. Template used to etch circuit patterns on semiconductor wafers. Images of the circuit pat-terns are produced on glass or metal photerns are produced on glass of metal pho-tographically. The mask is then used to control the diffusion process, plus met-allization. 6. A chrome or glass plate hav-ing the transparent circuit patterns of a single layer of a wafer. Masks are used in the defining of patterns on the surface of a resist-covered wafer. 7. Thin metals or other materials with an open pattern de-signed to mask off or shield selected por-tions of semiconductors or other surfaces during deposition processes. There also are photomasks or optical masks for contact or projection printing of wafers; these may use an extremely flat glass substrate with iron oxide, chrome, or emulsion coating, There also are thick-film screen masks. 8. The photographic negative that serves as the master for making thick-film screens and thin-film patterns. 9. The pattern, usually "printed" on glass, used to define areas of the chip or wafer. Masks are used for the diffusion, oxidation, and metallization steps used in manufacturing of semiconductors. 10. To hide, to obscure, to make less noticeable. For example, as noise masks crosstalk. 11. A material applied to enable selective etching,

IPB-BCM_00024982



masked diffusion-master clock etching, plating, or the application of solder to a printed board. Also, the surionizing chamber. They are then sent through electric and magnetic fields that sort them according to their ratios of mass face on which the master artwork of the circuit pattern is projected. 12. A thin steel arrangement with fine holes (shadow to charge. mass spectrum—The spectrum obtained by deflecting a beam of electrons with an electric or magnetic field as they emerge mask) or stripes (slot mask) that concentrates the electron beam at points on the from a tube containing a small quantity of masked diffusion — The use of a mask pattern to obtain selective impregnation of portions of a semiconductor material with impurity atoms. the gas being investigated. The amount a particle is deflected depends on the ratio of its mass to its atomic charge. Hence, every element has a characteristic massmasked ROM — A regular ROM produced by the usual masking process. (Contrasted with a PROM.) spectrum line. mass storage - 1. Refers to hardware devices providing massive amounts of onmasking—The process by which a sound is made audible by the addition of a second sound called the masking sound. line secondary storage, generally using strips of inexpensive magnetic media which can be accessed randomly, but with slower access times than those of conven-tional tape or disk devices. 2. Refers to peripheral devices into which programs The unit of measurement is usually the decibel. masking audiogram — A graphical representation of the amount of masking and data are stored for immediate action. by a noise. It is plotted in decibels as a 3. In a computer, secondary, slower memory for bulky files. Mostly floppy-disk, cassette, or tape. 4. Auxiliary memories, generally containing magnetic media, function of the frequency of the masked tone. mask microphone - A microphone de-MEDIES signed for use inside an oxygen or other which are used to supplement the main respiratory mask. mask set — A set of plates, usually glass, memory of a computer. It is less expensive than main memory per unit of information stored but it is slower to access. which are used to transfer a device topol-Examples include magnetic tape, magnetic disk, and flexible disk. 5. Auxiliary or bulk memory that can store large amounts of data readily accessible to the ogy in sequence to a wafer during fabrication. Masonite — Trade name of the Masonite Corp. Fiberboard made from steam-Corp. Fiberboard made from steam-exploded wood fiber. Its highly com-pressed forms are used for panels in elec-trical equipment. mass — 1. The quantity of matter in an object. It is equal to the weight of a body divided by the acceleration due to gravity. computer, e.g., a disk or magnetic tape. mass termination — The simultaneous termination of several or all conductors of a cable. This process generally uses terminals that pierce the insulation without stripping to cold-flow mate with the con-ductors and form a gas-tight metal-to-2. The bulk of matter though not necessarily equal to its weight. A mechanical unit whose electrical analog is inductance. mass data—A larger amount of data than can be stored in the central processing metal joint. See Insulation Displacement Connector. mast - The pole on which an antenna is mounted. unit of a computer at any one time. mass-memory unit — A drum or disk memory that provides rapid-access bulk storage for messages being held until outmaster -1. The mold from which other disc recordings are cast. It is made by elec-troforming from a disc recording, and is a "negative" of the disc (i.e., has ridges instead of grooves). 2. An original, or first special copy, of a recorded performance from which other copies may be made. 3. going channels are available. mass properties—Calculation of physical engineering information about a part, e.g., perimeter, area, volume, weight, and An original recording, made directly from moments of inertia. mass radiator — A spark radiator which generates a low-level, broadband signal recording microphones. A disc master is the lacquer original, usually cut from a tape from which stampers are made for vinyl pressings. 4. An element of a system that controls or initiates the action or re-sponses of the other elements of the extending into and above the ehf band. Arcing occurs between fine metal particles suspended in a liquid dielectric. mass spectrometer—An instrument that permits rapid analysis of chemical compounds. It consists of a vacuum tube into which a small amount of the gas to be master brightness control - In a color television receiver, a variable resistor that adjusts the bias level on all three guns in the picture tube at the same time. master clock — 1. In a computer, the primary source of timing signals. 2. A studied is admitted. The gas is ionized by the electrons emitted from the cathode and speeded up by an accelerating grid. An electric field draws the ions out of the very accurate timer with an absolute time

IPB-BCM 00024983

602

